

## Scout Hydration Purification System Instructions for Use

## **Installing RapidPure Scout in Your Hydration Pack**

Locate where you want to install the Scout on your hydration pack. Make sure once the Scout is installed the hydration tubing will not be pinched when using the Scout.

- 1. Cut the hydration line at desired location, typically near the mouth piece.
- 2. Insert RapidPure Scout hose barb ends into hydration pack hose.
- 3. Make sure the flow directional arrow of the Scout housing is going towards the hydration pack mouthpiece.
- 4. Double check hydration tubing is securely attached to Scout purification system hose barbs.
- 5. RapidPure Scout is now ready to be used in the hydration system!

## **Replacing Scout Purification Element**

- 1. Remove Scout top cap by turning it counter-clockwise 3/8" then pull top cap up and out of Scout purifier body housing.
- 2. Pull Scout purifier element out of Scout body housing.
- 3. Remove plastic wrapping from replacement Scout purifier element.
- 4. Do not puncture, slice, or crush Scout purifier element!
- 5. Insert and push Scout replacement purifier element into Scout housing making sure both purifier element o-rings are fully seated in the Scout housing discharge port. Make sure key tabs and slots lock shut.
- Insert Scout top cap in to housing then rotate top cap 3/8" clockwise until tabs of top cap are fully seated in groove of the body housing.
- 7. Make sure the top cap o-ring is not pinched or bunched up, if this occurs remove top cap and turn top cap ¼ turn to new location on housing and reinstall. If top cap o-ring still pinches or bunches up apply a bit of petroleum jelly or lip balm to top cap o-ring and reinstall top cap as directed above.
- 8. RapidPure Scout is now ready for use!

## RapidPure, Inc.

737 Quentin Ave. S. • Lakeland, MN 55043 Ph: 612.940.9946 • Fax: 651.490.3450 sales@RapidPureUSA.com • RapidPureUSA.com

**GET CONNECTED!** Log on to our website to learn more about our products and service. Products patented. Visit RapidPureUSA.com for information.



Make sure the flow directional arrow of the Scout housing is going towards the hydration pack mouthpiece.





Assembled in an ISO9001
Certified
Facility

Meets EPA & NSF guidelines with 99.9999% reduction of bacteria and viruses and 99.9980% reduction of protozoa and cysts

