



Universal Purifier Instructions for Use

Removing Pioneer Purifier from Pioneer Housing

1. To remove the purifier element from the Pioneer housing squeeze the Pioneer housing opposite of the cut away area at open end of the housing. By squeezing the Pioneer housing in this location the housing is made a bit oblong allowing the purifier element to be removed as the two tabs at the open end of the housing will move out/away allowing purifier element to be removed.
2. Grab the Pioneer purifier element in the cut away area of Pioneer housing and pull the purifier element out of the housing.

Installing Pioneer Purifier Element in Pioneer Straw

1. Remove plastic wrapping from the Pioneer purifier element.
2. Do not puncture, slice, or crush Pioneer purifier element!
3. Squeeze the Pioneer housing opposite of the cut away area at open end of the housing.
4. As a result, the housing will allow the purifier element to be installed. (The two tabs at the open end of the housing will move out/away allowing purifier element to be installed).
5. Insert and push Pioneer replacement purifier element into housing making sure both o-rings are fully seated in housing hose barb end.
6. RapidPure Pioneer Purifier is now ready for use!

Determining Length of Straw for Your Water Bottle

NOTE: The length of the straw that your Universal Purifier has been cut to should fit around 90% of water bottles on the market. If it does not fit your water bottle, a spare straw is included that you can cut to the desired length. Follow these directions.

1. Place the Universal Purifier cap unto your water bottle without the straw and Purifier.
2. Measure from the bottom of the cap to the bottom of your bottle. See example at right.
3. Subtract 3.25" from this measurement. This is the height that is taken up by the Purifier (with the straw snugly attached to it).
4. Cut your straw to desired length.
5. Attached Purifier to straw and attach Purifier/straw into cap.
6. Place cap on your bottle and your RapidPure Universal Purifier is now ready for use on your bottle.



RapidPure, Inc.

737 Quentin Ave. S. • Lakeland, MN 55043

Ph: 612.940.9946 • Fax: 651.490.3450

sales@RapidPureUSA.com • RapidPureUSA.com

GET CONNECTED! Log on to our website to learn more about our products and service. Products patented. Visit RapidPureUSA.com for information.